

**Recommended washing-instructions for:  
Karaat™, KaraatPlus™, ClassicBrush™**

**Normally soiled mats**

No.	Process	Comment	Time	Water	Temperature
1.	Flush		2 - 3 Min.	Medium	49°C
2.	Flush	optional	2 - 3 Min.	Medium	49°C
3.	Break	see No.3 below	5 - 10 Min.	High	49°C
4.	Rinse		2 Min.	High	cold
5.	Rinse		2 Min.	High	cold
6.	Extract	slow	1 - 2 Min.		
7.	Drain	drum turning	1 Min.		
8.	Extract	fast, max. 150 G	3 - 5 Min.		
9.	Dry	optional	5 - 10 Min.		max. 82°C
10.	Cool		5 Min.		

**Bitte unbedingt beachten:**

→	All solution-dyed mats can be washed together
→	For heavy soiled mats, increase temperature up to max. 71°C
→	Break should not exceed pH of 9,5; use low pH non-ionic detergents
→	Do not overdry mats; Basket-Temperature of Dryer max. 65°C!
→	If mats are not dried, temperature of last rinse can be increased to 49°C
→	Lay mats flat following removal from washer; allow mats to cool before rolling.